

Work Safe Bulletin

Workplace Lighting

The Cement Finishing Labour Relations Association is an Ontario not-for-profit ICI employer organization whose purpose includes the promotion of safe work planning and practices.

The purpose of this document is to provide specific hazard information and promote discussion of safe work practices.

This bulletin does not contain a full analysis of the law, nor does it constitute a legal opinion. The CFLRA is not liable for any damages resulting from the use of this information.

If you have any questions, please feel free to contact us at 289-837-1627 or by e-mail at safety@cflra.ca

Visit us online at
www.cflra.ca



Background:

Concrete finishers working require sufficient lighting to access and perform their work safely.

Hazard:

Inadequate lighting can hide hazardous situations which could lead to trips and falls.

Considerations:

Each project has unique characteristics that require careful consideration. It is strongly recommended that this issue be discussed at the preconstruction meeting with your safety representative. To reduce the possibility of an incident, it is recommended that the following be considered:

Ontario Construction Regulation 45 states: "The areas in which a worker is present and the means of access to and egress from those areas shall be adequately lit".

The Ontario Ministry of Labour considers a minimum of 5 foot candles (55 lux) as adequate from a housekeeping, access and egress perspective which can be achieved using 150 watt light bulbs suspended 2.4 metres high at 7.5 metres apart or 150 watt light bulbs suspended 3 metres high at 6 metres apart.

Note: The Ontario Building Code Table 9.34.2.7 calls for illumination to a minimum level of 50 lux and higher (depending upon usage).

Further references:

- [Ontario Regulation 213 for Construction Projects.](#)
- [Ontario Building Code.](#)

